


CHELSEA HOCKER 80x120



(D) Montageanleitung

(NL) Handleiding voor de montage

(TR) Montaj talimati

(F) Notice de montage

(CZ) Montážní návod

(GB) Assembly instructions

(HU) Szerelési útmutató




(PL) Instrukcja montażu

(RU) Инструкция по монтажу


(IT) Istruzioni di montaggio

(SK) Návod na montáž


(RO) Instrucțiuni de montaj




x1




x4








x24



x1







0-6



Service • Assistenza • Dienstverlening • Serwis • Servis • Szerviz • Сервисная служба

Name • Nom • Nome • Naam • Nazwa • Jméno • Názov • Név • Denumire • Isim • Название	CHELSEA
Nr • No. • N° • Номер • Č • Sz	80x120
Type • Tipo • Típus • Тип • Тип • Tip	HOCKER



A x....	B x....	C x....	D x....
----------------	----------------	----------------	----------------