


MALU 1237



(D) Montageanleitung

(FR) Notice de montage

(NL) Handleiding voor de montage

(CZ) Montážní návod

(HU) Szerelési útmutató

(TR) Montaj talimatı

(GB) Assembly instructions

(IT) Istruzioni di montaggio

(PL) Instrukcja montażu

(SK) Návod na montáž

(RO) Instrucțiuni de montaj




(RU) Инструкция по монтажу

Service • Assistenza • Dienstverlening • Serwis Servis • Szerviz • Сервисная служба


Name • Nom • Nome • Naam
Nazwa • Jméno • Názov • Név
Denumire • Ísim • Название

Nr. • No. • N° • Номер • Č • Sz

Typ • Type • Tip • Típus • Tipo
Тип



A Ø10: 01 PC



B Ø6: 16 PCS



C Ø6: 16 PCS



D Ø6/ Ø13 :16 PCS




E Ø6x15(mm): 16 PCS



F 04 PCS





A	Ø10	B	Ø6	C	Ø6	D	Ø6/ Ø13	E	Ø6x15mm	F	
											
01x		16x		16x		16x		16x		04x	

