


D Montageanleitung	GB Assembly instructions	NL Handleiding voor de montage	PL Instrukcja montażu	HU Szerelési útmutató	RO Instrucțiunile de montaj
FR Notice de montage	IT Istruzioni di montaggio	CZ Montážní návod	SK Návod na montáž	TR Montaj talimatı	RU Инструкция по монтажу


Service • Assistenza • Dienstverlening • Serwis
Servis • Szerviz • Сервисная служба

Imola
 7.4584





A5	0mm	4x
b3	KA37	4x
e11	24,3	14x
n	8x30mm	6x
s6	4x27	4x
v	192/214	2x
y4	Lein	1x
r9	0	4x
t1	3,5x15	8x

- 1. ASL 356x330x15mm 1
- 2. ASR 356x330x15mm 1
- 3. MDL 122x315x15mm 1
- 4. MDR 122x315x15mm 1
- 5. BL 1399x330x15mm 1
- 61. BD 1399x330x15mm 1
- 7. MSU 218x315x15mm 1
- 8. BLE 1399x61x15/16mm 1
- 9. KL 696x247x15/16mm 2
- 10. ZB 1367x315x15mm 1
- 11. RW 1379x239x3mm 1



A5	0mm	4x	s6	4x27	4x
b3	KA37	4x	t1	3,5x15	18x
e11	24,3	14x	t6	3,5x30	12x
f1		14x	v	192/214	2x
i	Klappenhalter 250	2x	x8	Fuß 58x40	6x
l		10x	y4	Lein	1x
n	8x30mm	14x	z		20x
r9	0	4x			



1

l		4x
f1		2x

2

f1		4x
----	--	----

3

f1		8x
n	8x30mm	8x

4

l		6x
z		20x

5

t6	3,5x30	12x
x8	Fuß 58x40	6x

6

i	Klappenhalter 250	2x
t1	3,5x15	10x

t1		10x
----	--	-----