



D Montageanleitung

GB Assembly instructions

FR Notice de montage

NL Handleiding voor de montage

CZ Montážní návod

IT Istruzioni di montaggio

RO Instrucțiuni de montaj




RU инструкция по сборке

PL Instrukcja montażu

SK Návod na montáž


HU Szerelési útmutató

TR Montaj talimati



0
10
20
30
40
50
60
70
80
90
100
110
120
130
140
150
160
170
180
190
200


Service • Assistenza • Dienstverlening • Serwis Servis • Szerviz • Сервисная служба	
Name • Nom • Nome • Naam Nazwa • Jméno • Názov • Név Denumire • İsim • Название	Joshua EB
Nr. • No. • N° • Номер • Č • Sz	SH45
Typ • Type • Tip • Típus • Тіро Тип	BK zerl. OHNE



A	B	C	D	E	F	G	H	I	J	K	L
4x	16x 4,5x20	4x	16x 6x25	4x	2x	2x 8x16	2x 8x20	2x M8	4x 8x60	4x 8x30	4x M8



0
10
20
30
40
50
60
70
80
90
100
110
120
130
140
150
160
170
180
190
200


Service • Assistenza • Dienstverlening • Serwis Servis • Szerviz • Сервисная служба	
Name • Nom • Nome • Naam Nazwa • Jméno • Názov • Név Denumire • İsim • Название	Joshua EB
Nr. • No. • N° • Номер • Č • Sz	SH45
Typ • Type • Tip • Típus • Тіро Тип	BK zerl. LARO



A	B	C	D	E	F	G	H	I	J	K	L
4x	16x 4,5x20	4x	16x 6x25	4x	2x	2x 8x16	2x 8x20	2x M8	4x 8x60	4x 8x30	4x M8








A		4x
B		16x 3,5x20







BKU-4S-4x-ALP-LS





C		4x
D		16x 6x25
E		4x






3.

F		2x
G		2x 8x16
H		2x 8x20
I		2x M8





L		4x M8
K		4x 8x30
J		4x 8x60