



ANTALYA WLS


- (DE) Montageanleitung
 (PL) Instrukcja montażu
 (NL) Handleiding voor de montage
 (GB) Assembly instructions
 (TR) Montaj talimatı
 (RU) Инструкция по монтажу
 (IT) Istruzioni di montaggio
 (FR) Notice de montage
 (RO) Instrucțiuni de asamblare
 (SK) Montážny návod
 (CZ) Montážní návod
 (HU) Szerelési útmutató



8 x (8x90) m	4 x (8x60) a	12 x O8 d	12 x M8 e	9 x (4x16) f	10 x (5x35) i	8 x g
10 x 50mm r	12 x j	18x k		2x 1	4x 2	



1 - ANTALYA WLS



2 - ANTALYA WLS