

Hadar



D Montageanleitung

GB Assembly instructions

FR Notice de montage

NL Handleiding voor de montage

CZ Montážní návod

IT Istruzioni di montaggio

RO Instrucțiuni de montaj


RU инструкция по сборке

PL Instrukcja montażu

SK Návod na montáž


HU Szerelési útmutató

TR Montaj talimati




Service • Assistenza • Dienstverlening • Serwis Servis • Szerviz • Сервисная служба

Name • Nom • Nome • Naam Nazwa • Jméno • Názov • Név Denumire • Ísim • Название	Hadar EB	
Nr. • No. • N° • Номер • Č • Sz	SH56	
Typ • Type • Tip • Típus • Tipo Тип	BS	



A	B	C
4x	4x 8x45	4x8x20



A	B	C
		
4x	4x 8x45	4x 8x20
70		

