




"HAPPY" TV-Paneel



Montageanleitung



Handleiding voor de montage



Montaj talimati



Istruzioni di montaggio



Montážní návod



Instrucțiuni de montaj



Assembly instructions



Instrukcja montazu



Инструкция по сборке






Notice de montage



Szerelési útmutató



Návod na montáž



Name • Nom • Nome • Naam • Nazwa • Jméno • Názov • Név • Denumire • Isim • Название

HAPPY




Typ • Type • Tip • Típus • Тіро • Тип








TV-Paneel

Nr. • No. • N° • Номер • Č • Sz

770 561 / 769 486

 **Walnuss / Weiß**



A3 	B3 	C1  Ø8x30	H1  Leim	T1  7,7 x 45	U5 	
8	8	12	1	11	2	

