


"AQUA 2" TV-Lowboard 140



D

Montageanleitung

GB

Assembly instructions

NL

Handleiding voor de montage

PL




Instrukcja montazu

TR

Montaj talimati

RU

Инструкция по сборке



Service • Dienstverlening • Serwis • Servis • Сервисная служба

Name • Naam • Nazwa • Isim • Название

AQUA 2




Typ • Type • Тiп • Тип




















TV-Lowboard 140cm






Nr. • No. • Номер


386 124 / 398 763

 **Schwarz / Weiß**



A1  16	B1  16	C1  Ø8x30 16	D5  2	E10  2 mm 2	F16  Kr.0 mm 2	F20  2	F21  2	K11  6
L1  4	M31  577mm 1	M32  2	N2  2,7 x 20 6	N12  4,0 x 25 3	P9  3,5 x 25 12	P10  3,5 x 13 4	P2  3,5 x 13 4	
S1  16	W4  1							





6

1

90°

L1

39,5cm

58,4cm

39,5cm

N2

90°

