








- | | | | |
|----|------------------------|----|-----------------------------|
| D | Montageanleitung | GB | Assembly instructions |
| FR | Notice de montage | NL | Handleiding voor de montage |
| CZ | Montážní návod | IT | Istruzioni di montaggio |
| RO | Instructiuni de montaj | RU | инструкция по сборке |
| PL | Instrukcja montazu | SK | Návod na montáž |
| HU | Szerelési útmutató | TR | Montaj talimati |



Service • Assistenza • Dienstverlening • Serwis Servis • Szerviz • Сервисная служба

Name • Nom • Nome • Naam Nazwa • Jméno • Názov • Név Denumire • İsim • Название	Tom EB
Nr. • No. • N° • Номер • Č • Sz	SH51
Typ • Type • Tip • Típus • Tipo Тип	BK zerl. OHNE



1

3

4


5

2


A	B	C	D	E	F	G	H	I	J
4x	16x 3,5x20	4x	16x 6x25	4x	4x	4x 8x20	4x 8x70	4x 8x40	4x M8


Service • Assistenza • Dienstverlening • Serwis Servis • Szerviz • Сервисная служба

Name • Nom • Nome • Naam Nazwa • Jméno • Názov • Név Denumire • İsim • Название	Tom EB
Nr. • No. • N° • Номер • Č • Sz	SH51
Typ • Type • Tip • Típus • Tipo Тип	BK zerl. LARO






A	B	C	D	E	F	G	H	I	J
4x	16x 3,5x20	4x	16x 6x25	4x	4x	4x 8x20	4x 8x70	4x 8x40	4x M8

A	B
	
4x	16x 3,5x20








C		4x
D		16x 6x25
E		4x






BKU-4S-WI-4x-FUSS

F		4x
G		4x 8x20





Achtung! Schrauben nicht überdrehen		GB	Watch Out! Do not over tighten
H	I	J	
			FR Attention! Ne serrez pas trop
			CZ Dávej Pozor! Nepřetahujte
			RO Ai Grija! Nu strângeți
			PL Uważaj! Nie dokręcać zbyt mocno
4x 8x70	4x 8x40	4x M8	HU Vigyázz! Ne húzza túl
			TR Dikkat! Üzerinde sıkmayın
			RU Осторожно! Не затягивайте
			SK Dávaj Pozor! Nepreťahujte
			NL Let Op! Niet te vast
			IT Attento! Non stringere

