







NEW CASTLE 3




- (D) Montageanleitung
- (NL) Handleiding voor de montage
- (TR) Montaj talimati
- (F) Notice de montage
- (CZ) Montážní návod
- (GB) Assembly instructions
- (HU) Szerelési útmutató
- (PL) Instrukcja montażu
- (RU) Инструкция по монтажу
- (IT) Istruzioni di montaggio
- (SK) Návod na montáž
- (RO) Instrucțiuni de montaj




x1








x4



x4



0-6



Service • Assistenza • Dienstverlening • Serwis •
 Servis • Szerviz • Сервисная служба

| | |
|---|---------------|
| Name • Nom • Nome • Naam • Nazwa • Jméno • Název • Név • Denimire • Isim • Название | NEW CASTLE |
| Nr • No. • N° • Номер • Č • Sz | |
| Type • Tipo • Típus • Typ • Тип • Тір | 3 |

