

Ⓓ Aufbauanleitung

Ⓕ Notice de montage

Ⓖ Montagehandleiding

Ⓒ Montážní návod

Ⓗ Szerelési útmutató

Ⓙ Montaj talimatları

Ⓖ Assembly instruction

Ⓙ Istruzioni di montaggio





Ⓙ Instrukcja montażu

Ⓙ Navod na montaž

Ⓙ Instrucțiuni de montaj

Ⓙ Инструкция по монтажу

36-4281-82-09A





Service • Assistenza • Dienstverlening • Serwis Servis • Szerviz • Сервисная служба

Name • Nom • Nome • Naam • Nazwa • Jméno • Názov
Név • Denumire • Isim • Название






Nr. Nr. • No. • N° • Č • Sz • Номер

Typ • Тип • Type • Tip • Tipus • Druh • Тіро • Тип




Detail specification

A.i. Nr.	Article Nr.	pcs
3	208748-32	x2
4	108820-00	x16




Fitting specification


A.i. Nr.	Article Nr.	Dimensions	pcs
a	1-000013-00	8x40	x4
b	1-000084-07	10x46	x8
c	1-000085-07	16x20	x8
d	1-000086-07	M10x14	x8
e	1-000012-07	3x30	x32
f	1-000087-07	4x70	x4



a




b




c



d




e




f


1-000001=




1.



2.



3.



Ⓓ Aufbauanleitung

Ⓕ Notice de montage

Ⓖ Montagehandleiding

Ⓒ Montážní návod

Ⓗ Szerelési útmutató

Ⓙ Montaj talimatları

Ⓖ Assembly instruction

Ⓙ Istruzioni di montaggio






Ⓙ Instrukcja montażu

Ⓙ Navod na montaž

Ⓙ Instrucțiuni de montaj

Ⓙ Инструкция по монтажу

36-4285-82-000





Service • Assistenza • Dienstverlening • Serwis Servis • Szerviz • Сервисная служба






Name • Nom • Nome • Naam • Nazwa • Jméno • Názov
Név • Denumire • Isim • Название

Nr. • No. • N° • Č • Sz • Номер

Typ • Type • Tip • Tipus • Druh • Тип • Тип








2	169225-82	x1
6	208778-32	x1
7	208779-32	x1



g

mm
g1-000094-07 4x40 x2



Ⓓ Aufbauanleitung

Ⓕ Notice de montage

Ⓖ Montagehandleiding

Ⓒ Montážní návod

Ⓗ Szerelési útmutató

Ⓙ Montaj talimatları

Ⓖ Assembly instruction

Ⓙ Istruzione di montaggio






Ⓙ Instrukcja montażu

Ⓙ Navod na montaž

Ⓙ Instrucțiuni de montaj

Ⓙ Инструкция по монтажу

36-4286-82-000





Service • Assistenza • Dienstverlening • Serwis Servis • Szerviz • Сервисная служба

Name • Nom • Nome • Naam • Nazwa • Jméno • Názov
Név • Denumire • Isim • Название


Nr. • No. • N° • Č • Sz • Номер

Typ • Type • Tip • Tipus • Druh • Tipo • Тип






Detail specification


A.i. Nr.	Article Nr.	pcs
①	169224-82	x1
⑥	208778-32	x1
⑦	208779-32	x1




	mm	
g1-000094-07	4x40	x2



1.



2.



3.

3.1

