




- | | | | |
|----|-----------------------------|----|-------------------------|
| Ⓓ | Montageanleitung | ⒼⒷ | Assembly instructions |
| ⒻⓇ | Notice de montage | ⒾⓉ | Istruzioni di montaggio |
| ⓃⓁ | Handleiding voor de montage | ⓅⓁ | Instrukcja montażu |
| ⒸⓏ | Montážní návod | ⓈⓀ | Návod na montáž |
| ⒽⓊ | Szerelési utmutató | Ⓡⓞ | Instrucțiuni de montaj |
| ⓉⓇ | Montaj talimatı | ⓇⓊ | Инструкция по монтажу |

Ausgabe:2022 1010








Service • Assistenza • Dienstverlening • Serwis Servis • Szerviz • Сервисная служба	
Name • Nom • Nome • Naam Nazwa • Jméno • Názov • Név Denumire • Isim • Название	
Nr. • No. • N° • Номер • С. Sz	3572 0359/7002 4409
Typ • Type • Tip • Típus • Tipo Тип	YS-WR7026




A M6X12MM X12	B X1	C M4X40MM X12	D X4
--------------------------------	--------------------	--------------------------------	--------------------






1

A	M6X12MM	B	
	X12		X1



2

<p>C</p> <p>M4X40MM</p>  <p>X12</p>	<p>D</p>  <p>X4</p>
--	--



3

