


ART.NR. 41101451



ART.NR. 91700768

LKZ: 40827



- (D) Montageanleitung
- (FR) Notice de montage
- (NL) Handleiding voor de montage
- (CZ) Montážní návod
- (HU) Szerelési útmutató
- (TR) Montaj talimatı
- (SLO) Navodila za montažo

- (GB) Assembly instructions
- (IT) Istruzioni di montaggio
- (PL) Instrukcja montażu
- (SK) Návod na montáž
- (RO) Instrucțiuni de montaj
- (RU) Инструкция по монтажу
- (HR) Shema montaže






10 min

**Service • Assistenza • Dienstverlening • Serwis
Servis • Szerviz • Сервисная служба**

Name • Nom • Nomo • Naam •
Nazwa • Jméno • Názov • Név •
Denumire • İsim • Название


Nr. • No. • N° • Номер • Č • Sz
41101451,91700768

Typ • Type • Típus •
Típus • Tipo • Тип



2x

A



2x

B



Ø3,5x16

16x

C

