


# "AQUA 2" TV-Lowboard 160



D

Montageanleitung

GB

Assembly instructions

NL

Handleiding voor de montage

PL



Instrukcja montazu

TR

Montaj talimati

RU

Инструкция по сборке



# Service • Dienstverlening • Serwis • Servis • Сервисная служба

Name • Naam • Nazwa • Isim • Название

**AQUA 2**




Typ • Type • Тір • Тип




















**TV-Lowboard 160cm**





Nr. • No. • Номер


**391 956 / 398 098**




 **Schwarz / Weiß**











<b>A1</b>  <b>16</b>	<b>B1</b>  <b>16</b>	<b>C1</b>  Ø8x30 <b>16</b>	<b>D5</b>  <b>2</b>	<b>E10</b>  2 mm <b>2</b>	<b>F16</b>  Kr.0 mm <b>2</b>	<b>F20</b>  <b>2</b>	<b>F21</b>  <b>2</b>	<b>K11</b>  <b>6</b>
<b>L1</b>  <b>4</b>	<b>M26</b>  777mm <b>1</b>	<b>M54</b>  <b>2</b>	<b>N2</b>  2,7 x 20 <b>6</b>	<b>N12</b>  4,0 x 25 <b>4</b>	<b>P9</b>  3,5 x 25 <b>12</b>	<b>P10</b>  3,5 x 13 <b>4</b>	<b>P13</b>  3,5 x 12 <b>4</b>	
<b>S1</b>  <b>16</b>	<b>W4</b>  <b>1</b>							















M54

