








- | | |
|----------------------------------|------------------------------|
| (D) Montageanleitung | (FR) Notice de montage |
| (NL) Handleiding voor de montage | (CZ) Montážní návod |
| (HU) Szerelési útmutató | (TR) Montaj talimatı |
| (GB) Assembly instructions | (IT) Istruzioni di montaggio |
| (PL) Instrukcja montażu | (SK) Návod na montáž |
| (RO) Instrucțiuni de montaj | (RU) Инструкция по монтажу |

**Service • Assistenza • Dienstverlening • Serwis
Servis • Szerviz • Сервисная служба**

Name • Nom • Nome • Naam •
Nazwa • Jméno • Názov • Név •
Denumire • Isim • Название

Nr. • No. • N° • Номер • Č • Sz

Typ • Type • Tip • Típus • Tipo •
Тип








1	1x	ca. 1385 x 350 mm
2	1x	ca. 1366 x 680 mm
3	1x	ca. 1385 x 330 mm
4	1x	ca. 668 x 330 mm

5	1x	ca. 668 x 330 mm
6	2x	ca. 326,5 x 315 mm
7	1x	ca. 1354 x 315 mm
8	1x	ca. 933 x 330 mm
9	1x	ca. 933 x 338 mm





A 8,0 x 30 mm 20x	B 20x	C 20x	D h=2 4x	E 3,5 x 13 mm 12x	F 6x	G 4,0 x 20 mm 6x
H Ø35 Kr.8 3,5x13 mm 4x	I 250 mm 2x	J 2,7 x 20 mm 5x				













1






2




3




A 8,0 x 30 mm  20x	B  8x	C  20x	D  2x	E 3,5 x 13 mm  6x
F  250 mm 2x				



5




6





MA1

7



8





9

E 3,5 x 13 mm




6x



- (D) Bremsekraft einstellen
- (GB) Adjust brake force
- (FR) Réglez la force de freinage
- (IT) Regola la forza frenante
- (NL) Pas de remkracht aan
- (PL) Dostosuj siłę hamowania
- (CZ) Seříd'te brzdnou sílu
- (RO) Reglați forța de frână
- (HU) Állítsa be a fékerőt
- (SK) Nastavte brzdnú silu
- (TR) Fren gücünü ayarlayın
- (RU) Отрегулируйте тормозное усилие

- (D) Türen einstellen (Scharniere justieren)
- (GB) Adjusting the doors (adjusting the hinges)
- (FR) Régler les portes (ajuster les charnières)
- (IT) Sistemare le porte (regolare le cerniere)
- (NL) Deuren instellen (scharnieren afstellen)
- (PL) Nastawić drzwi (wyregulować zawiasy)
- (CZ) Vyrovnajte dvířka (seříd'te závěsy)
- (RO) Nastavenie dverí (nastavenie závesov)
- (HU) Állítsa be az ajtókat (állítsa be a zsanérokat)
- (SK) Reglare uši (ajustare balamale)
- (TR) Kapıların ayarlanması (menteşelerin seviye ayarı)
- (RU) Регулировка дверей (регулировка шарнира)



(D) Türen einstellen
(Scharniere justieren)

(GB) Adjusting the doors
(adjusting the hinges)

(FR) Régler les portes
(ajuster les charnières)

(IT) Sistemare le porte
(regolare le cerniere)

(NL) Deuren instellen
(scharnieren afstellen)

(PL) Nastawić drzwi
(wyregulować zawiasy)

(CZ) Vyrovnajte dvířka
(seřid'te závěsy)

(RO) Nastavenie dverí
(nastavenie závesov)

(HU) Állítsa be az ajtókat
(állítsa be a zsanérokat)

(SK) Reglare uši
(ajustare balamale)

(TR) Kapıların ayarlanması
(menteşelerin seviye ayarı)

(RU) Регулировка дверей
(регулировка шарнира)

